

N55: Which Harness Do I Need?

Early N55 models have a different HPFP electrical connection than the later cars. Technically the cutoff is a build date of **12/2013** and later for the **New Style Connector** and anything before 12/2013 for the **Old Style Connector**.

HOWEVER, we highly recommend anyone in the **12/2013-6/2014** range to do a **visual check** on their harness!

Build Date Check:

An easy way to check your build date is to enter your VIN here: <https://www.realoem.com/bmw/enUS/select>

Enter your BMW Serial Number (last 7 digits of your VIN) OR use the search options below.

Serial Number: Search Catalog: 12/2019

PART NR APPLICATION SEARCH: Search

Product:	Series:	Body:	Model:	Market:	Prod Month:	Engine:
Car	7' G11 LCI (2018 — 2020)	SUV	X1 16i	USA	2013	N55
Motorcycle	7' G12 (2014 — 2019)		X1 18d		01/2013	
	7' G12 LCI (2018 — 2020)		X1 18dX		02/2013	
	8' G14 (2017 — 2019)		X1 18i		03/2013	
Catalog:	8' F91 M8 (2017 — 2019)		X1 20d		04/2013	
Current	8' G15 (2017 — 2019)		X1 20d ed		05/2013	
Classic	8' F92 M8 (2017 — 2019)		X1 20dX		06/2013	
	8' G16 Gran Coupé (2018 — 2019)		X1 20i		07/2013	
	8' F93 M8 (2018 — 2019)		X1 20iX		08/2013	
	i3 I01 (2013 — 2017)		X1 23dX		09/2013	
	i3 I01 LCI (2017 — 2019)		X1 25dX		10/2013	
	i8 I12 (2013 — 2018)		X1 25iX		11/2013	
	i8 I12 LCI (2016 — 2019)		X1 28i		12/2013	
	i8 I15 (2017 — 2019)		X1 28iX		2014	
	X1 E84 (2008 — 2015)		X1 35iX		01/2014	

You Have Selected: X1 E84 BMW X1 35iX. Type Code: VM53

For the VIN above, the car actually still has an OLD style harness! It's hit or miss between 12/2013 and 6/2014.

Visual Check:

For most vehicles, you can simply remove the airbox and check the connector style with a flash light. The HPFP is located below the intake manifold and can be viewed between the intake runners:



